



NO.	114H PART NO.	114HL	114HLW PART NO.	DESCRIPTION
1	1-114H	1-114H	1-114H	Right Side Plate
2	2-114H-O	2-114H-O	2-114H-O	Outer Right Side Ring
2A	2-114-I	2-114-I	2-114-I	Inner Side Ring (2 req.)
3	3-114H	3-114H	3-114H	Bridge w/Sleeve
4	4-115	4-115	4-115	Fiber Washer
5	5-115	5-115	5-115	Main Gear
6	6-115	6-115	6-115	Drag Washer (5 req.)
7	7C-115	7C-115	7C-115	Metal Drag Washer Set
8	8-114	8-114	8-114	Tension Spring (Set of 2)
8A	8-115	8-115	8-115	Tension Spring
9	9-114H	9-114H	9-114H	Spacing Sleeve
10	10-114	10-114	10-114	Star Drag Wheel
11	11-114	11-114	11-114	Eccentric Jack
12	12-114	12-114	12-114	Pinion Yoke
13	13-114H	13-114H	13-114H	Pinion
14	14-114	14-114	14-114	Dog Spring
15	15-114H	15-114H	15-114H	Dog
16	16-114	16-114	16-114	Lower Bridge Screw (2 req.)
17	17-114	17-114	17-114	Upper Bridge Screw (2 req.)
18	18-114	18-114	18-114	Clutch Spring (2 req.)
18A	18-114H	18-114H	18-114H	Spring Disc
19	19-114	19-114	19-114	Eccentric
20	20-114	20-114	20-114	Eccentric Spring
21	21-114	21-114	21-114	Eccentric Lever
22	23-60	23-60	23-60	Eccentric Screw
23	23-116	23-116	23-116	Handle Screw
23A	110-60	110-60	110-60	Handle Lock Screw
24	24-115	24-57	24-57	Handle
26	26-116	26-116	26-116	R.S. Bearing
27	27N-114H	27N-114H	27N-114H	Left Side Plate
28	2-114-O	2-114-O	2-114-O	Outer Left Side Ring
29L	29M-114H	29L-114HL	29L-114HLW	Spool
30	30-114	30-114HL	30-114HL	Stand
31	31-11			R.S. Stand Screw (3 req.)
32	32-20			L.S. Stand Screw (3 req.)
33	33-340	33-340	33-340	Rod Clamp
	*33R-114	*33R-114	*33R-114	Ringed Rod Clamp (Optional)
34	34-45			Clamp Screw (2 req.)
		34-114HLW	34-114HLW	Rod Clamp Screw (2 req.)
34C	34C-45			Rod Clamp Screw w/Nuts
35	35-114	35-114	35-114	Click Tongue
36	36-114H	36-114H	36-114H	Click Button
37	37-114 (5 req.)	37-114	37-115	Frame Post
38	39-13 (5 req.)	39-12 (8 req.)	39-12 (8 req.)	R.S. Plate Screw
39	32-12 (5 req.)	32-21 (8 req.)	32-21 (8 req.)	L.S. Plate Screw
40	40-114HL	40-114HL	40-114HL	Left Side Bearing
40A	120-114H	120-114H	120-114H	Left Side Bearing O-Ring
54	54-114	54-114	54-114	Harness Lug (2 req.)
62	62-114	62-114	62-114	Click Spring
62A	63-209	63-209	63-209	Click Spring Screw
69	69B-600	69B-600	69B-600	Retaining Ring
98	98-114	98-114	98-114	Gear Sleeve
118		118-80	118-80	Stand Screws (4 req.)
149	149-45	149-45	149-45	Rod Clamp Nut (2 req.)
149A	149-200			Hex Nut (2 req.)
183		183N-114HL	183N-114HLW	Frame

*Not Shown